CHAPTER

11

PLACARDS AND MARKINGS





CHAPTER 11 - PLACARD AND MARKINGS LIST OF EFFECTIVE PAGES

CHAPTER		
SECTION SUBJECT	PAGE	DATE
11-LOEP	1	Dec. 15/09
	2	Dec. 15/09
11-TOC	1	Dec. 15/09
	2	Dec. 15/09
11-00-00	1	Dec. 15/09
	2	Dec. 15/09
	3	Dec. 15/09
	4	Dec. 15/09
11-10-00	201	Dec. 15/09
	202	Dec. 15/09
11-20-00	201	Dec. 15/09
	202	Dec. 15/09
	203	Dec. 15/09
	204	Dec. 15/09
	205	Dec. 15/09
	206	Dec. 15/09
	207	Dec. 15/09
	208	Dec. 15/09
11-30-00	201	Dec. 15/09
	202	Dec. 15/09
	203	Dec. 15/09
	204	Dec. 15/09
	205	Dec. 15/09
	206	Dec. 15/09

EFFECTIVITY:
Page 1
Dec. 15/09



EFFECTIVITY:

Page 2 Dec. 15/09

CHAPTER 11 - PLACARD AND MARKINGS TABLE OF CONTENTS

SUBJECT	CHAPTER SECTION SUBJECT	PAGE	EFFECTIVITY
PLACARDS AND MARKINGS Description and Operation 1. General	11-00-00	1 1	
EXTERIOR COLOR Maintenance Practices 1. General	11-10-00	201 201	
EXTERNAL PLACARDS Maintenance Practices 1. General 2. Placard - Removal 3. Placard - Installation	11-20-00	201 201 201 201	
INTERNAL PLACARDS Maintenance Practices 1. General 2. Placard - Installation	11-30-00	201 201 201	

EFFECTIVITY:

Page 1
Dec. 15/09



EFFECTIVITY:

Page 2 **11-TOC** Dec. 15/09

PLACARDS AND MARKINGS - DESCRIPTION AND OPERATION

1. General

- The model designation placard is located at the rear of the fuselage on the left side af FS 8590. The placard identifies the airplane by its identification mark, aircraft type, manufacturer and serial number.
- B. For information of the internal and external placards refer to the following Table:

EXTERNA	AL PLACARDS	INTERNA	AL PLACARDS
NUMBER OF PLACARD	PART NUMBER	NUMBER OF PLACARD	PART NUMBER
1	80-899001-025	1	80-118997-001
2	80-899001-007	2	80K118789-001
3	80-899001-005	3	80-118997-007
4	80-899001-009	4	80K118328-001
5	80-899001-011	5	80-899001-079
6	80-899001-021	6	80-118997-005
7	80-899001-043	7	80K118787-003
8	80-899001-039	8	80K118787-001
9	80-899001-037	9	80-899001-075
10	80-899001-041	10	80-899001-085
11	80-899001-013	11	80-899001-077
12	80-899001-017	12	80-899001-067
13	80-899001-015	13	80-899001-069
14	80-899001-019	14	not used
15	80-899001-067	15	not used
16	80-899001-023	16	80-899001-061
17	80-899001-045	17	80-899001-063
18	80-899001-065	18	80-899001
19	80-899001-001	19	80-198162
20	80-899001-003	20	80-899002
21	80-899001-053	21	80-899002
22	80-899001-035	22	80-899002
23	80-KS00009	23	80-899002
24	80-909789	24	80-899002
25	80-899001-029	25	80-899002
26	not used	26	80-899002
27	80-899001-031	27	80-899002
28	80-899001-027	28	80-899002
29	80-899001-081	29	80-899002
30	80-899001-047	30	80-899002
31	80-899001-049	31	not used
32	80-899001-051	32	not used


EFFECTIVITY: Page 1 Dec. 15/09



EXTER	RNAL PLACARDS	INTER	NAL PLACARDS
33	80-899001-083	33	80-899002
		34	80-899002
		35	80-899002
		36	80-899002
		37	80-899002
		38	80-899002
		39	80-899002

Page 2 EFFECTIVITY: 11-00-00 Dec. 15/09





А

PIAGGIO AERO INDUSTRIES S.p.A.

GENOA ITALY

MODEL P. 180 AVANTI II

SERIAL NUMBER

AIRCRAFT TYPE CERTIFICATE: EASA A.059
AIRCRAFT TYPE CERTIFICATE: FAA A59EU

 \bigcirc

MM 110000

Fig. 1 - Model Designation Placard

EFFECTIVITY:

Page 3

Dec. 15/09

11-00-00



EFFECTIVITY:

Page 4 11-00-00 Dec. 15/09

EXTERIOR COLOR - MAINTENANCE PRACTICES

1. General

- A. The exterior color scheme is a customer option in accordance with Design Authority Approval.
- B. Composite components classified as primary structures in Chapter 51-01-00 are subject to the following limitations for application of exterior paints:
 - Color listed in table WARNING: are approved for application without limitation.
 - Other colors or decals may be applied provided no more than 20% of the external surface is affected. The limit of 20% must be considered as distributed over the entire surface, not as a concentrated area.
 - For application of other colors over the entire surface contact the airplane Manufacturer for evaluation of paint optical properties.

These paints are also listed in Chapter 91-00-00, Chart 201 Item 05-006. The composite material areas and structural classification are shown in Chapter 51-00-00.

WARNING: APPLICATION OF COLORS OTHER THAN THOSE LISTED IN TABLE WARNING: MAY CAUSE EXCESSIVE TEMPERATURES AND CONSEQUENT DEGRADATION OF STRUCTURAL PROPERTIES OF COMPOSITE COMPONENTS..

VENDOR	COLO	R P/N
ALUMIGRIP	- Ethereal Blu	e G8036
ALUMIGRIP	- Beyond Blue	H5002
ALUMIGRIP	- Ice Blue	H5004
ALUMIGRIP	- Snow White	G8044
ALUMIGRIP	- Vestal White	G8004
ALUMIGRIP	- Off White	G8010
ALUMIGRIP	- Off White Re	evised G8009
ALUMIGRIP	- Oyster White	е Н8010
ALUMIGRIP	- Egg Shell W	hite H8015
ALUMIGRIP	- Matterhorn	White G8003
ALUMIGRIP	- Blue Tone W	Thite G8029
ALUMIGRIP	- Cream	H8002
ALUMIGRIP	- Moon Dust	G6004
ALUMIGRIP	- Tender Yello	w G9059
ALUMIGRIP	- San Mateo V	Wheat G9001

Table 201

EFFECTIVITY:
Page 201
11-10-00
Dec. 15/09



Page 202 EFFECTIVITY:

EXTERNAL PLACARDS - MAINTENANCE PRACTICES

1. General

A. In this section are shown the external placards and their locations on the airplane (Ref. to Fig. 201).

2. Placard - Removal

A. Materials

Methyl-Ethyl-Ketone (MEK) solvent TT-M-261 Lint-Free Cloth Not Specified

B. Procedure

WARNING: BE CAREFUL WHEN YOU USE MEK. OBEY THE HEALTH AND SAFETY INSTRUCTIONS GIVEN IN CHAPTER 20-00-00.

NOTE: When placards are located close to each other, it is advisable to replace the adjacent placard(s) when replacing a specific placard.

- (1) Detach the placard from the airplane using a hot air blower to soften the adhesive, taking care not to damage any adjacent component or paint work.
- (2) Clean the surface with the MEK solvent (TT-M-261) and a lint-free cloth.

3. Placard - Installation

A. Materials

Isopropyl Alcohol 02-008
Methyl-Ethyl-Ketone (MEK) solvent TT-M-261
Lint-Free Cloth Not
Specified

B. Procedure

WARNING: BE CAREFUL WHEN YOU USE MEK. OBEY THE HEALTH AND SAFETY INSTRUCTIONS GIVEN IN CHAPTER 20-00-00.

NOTE: The Scotchcal materials, being self-adhesive, can be applied to the most smooth, flat, clean and non-porous surfaces.

- (1) Clean the surface with a cloth, made moist with the MEK solvent (TT-M-261).
- (2) Wipe carefully with a clean lint-free cloth.

WARNING: BE CAREFUL WHEN YOU USE ISOPROPYL ALCOHOL. OBEY THE HEALTH AND SAFETY INSTRUCTIONS GIVEN IN CHAPTER 20-00-00.

EFFECTIVITY: Page 201
11-20-00 Dec. 15/09

PIAGGIO P.180 AVANTI II MAINTENANCE MANUAL

International AeroTech Academy For Training Purpose Only



- (3) Remove the protective covering from the adhesive side of the placard.
- (4) Position the placard and press firmly to the surface.

NOTE: In order to get the best results placards must be applied at a temperature higher than 60 °F (16 °C). Whenever a placard must be applied at a lower temperature, activate the adhesive with a small quantity of isopropyl alcohol.

EFFECTIVITY: Page 202 11-20-00






Fig. 201 - (Sheet 1 of 5) - External Placard and Marking Locations

Page 203 Dec. 15/09

11-20-00






Fig. 201 - (Sheet 2 of 5) - External Placard and Marking Locations

Page 204 Dec. 15/09






Fig. 201 - (Sheet 3 of 5) - External Placard and Marking Locations

Page 205 Dec. 15/09





NO STEP



ECS OIL MIL-L-23699 TANK CAPACITY 53 CC.

- 1. ECS DRAIN VALVE: OPEN
 2. FILL TO OVERFLOW FROM
 ECS DRAIN VALVE
 3. ECS DRAIN VALVE: CLOSE

DETAIL B



FILLING INSTRUCTION

- 1. OPEN OVERFILLING VALVE ON L.G. BAY
- 2. REMOVE PLUG FROM FILLING PORT AND CONNECT HOSE FROM HAND PUMP
- 3. PUMP OIL MIL-H-5606 OR EQUIVALENT TO OVERFLOW FROM OVERFILLING VALVE
- 4. OIL CAPACITY FROM LOW LEVEL TO MAX LEVEL 200 CC.
- 5. REMOVE HOSE AND PLUG FILLING PORT
- 6. CLOSE OVERFILLING VALVE



12

HYD. OIL FILLING PORT

ECS OIL UNDER **BAGGAGE FLOOR**

Fig. 201 - (Sheet 4 of 5) - External Placard and Marking Locations






Fig. 201 - (Sheet 5 of 5) - External Placard and Marking Locations

Page 207 EFFECTIVITY: 11-20-00 Dec. 15/09



Page 208 EFFECTIVITY: 11-20-00

Dec. 15/09

INTERNAL PLACARDS - MAINTENANCE PRACTICES

1. General

- A. In this section are shown the internal placards and their locations on the airplane (Ref. to Fig. 201).
- B. Placard Removal

NOTE: It is possible to remove the placards 27, 34 and 26 (Ref. to Fig. 201); all other placards are stencilled.

- (1) Detach the placard from the surface. Use a plastic tool, taking care not to damage the surface.
- (2) Clean the surface with an applicable solvent (Ref. to Chapter 51-00-00).

2. Placard - Installation

- (1) Make sure that the surface is clean.
- (2) Attach the new placard on the related surface pressing firmly.

EFFECTIVITY:
Page 201

11-30-00 Dec. 15/09






Fig. 201 - (Sheet 1 of 5) - Internal Placard and Marking Locations

Page 202 Dec. 15/09






Fig. 201 - (Sheet 2 of 5) - Internal Placard and Marking Locations

EFFECTIVITY: Page 203
11-30-00 Dec. 15/09






Fig. 201 - (Sheet 3 of 5) - Internal Placard and Marking Locations

Page 204 Dec. 15/09

11-30-00






Fig. 201 - (Sheet 4 of 5) - Internal Placard and Marking Locations

EFFECTIVITY: 11-30-00

Page 205 Dec. 15/09






Fig. 201 - (Sheet 5of 5) - Internal Placard and Marking Locations

Page 206
Dec. 15/09